

AWO GCO

The airport is equipped with a GCO
(Ground Communications Outlet)
To access the GCO use frequency:

121.72

Pilots may contact TRACON, Wx Brief, Airport Operations and Emergency Services via the GCO.

- To contact **TRACON**, click the mic **2** times
- To contact **Wx Brief**, click the mic **4** times
- To contact **Airport Operations** (“Hardstand”), click the mic **6** times
- To contact **Emergency Services**, click the mic **8** times

The system will ask you to click the mic twice to acknowledge it is dialing the correct location. (If it is not correct location, wait 5 seconds and start again.)

The GCO will then dial the appropriate number. You will hear it dialing. When the person answers just communicate your needs via the radio-telephone link.

To terminate the call, click the mic 3 times while the frequency is clear and the call will be terminated.

HINTS:

If there is no voice activity over the system for 60 seconds (told to standby, etc.), **it will say “Timing Out”, key the mic within 3 seconds and that will get an extra 30 seconds of “no voice time”.**

If the system does not respond at first, try repositioning your aircraft for a clear path to the antenna at the airport office (mid-field, eastside).

For Questions regarding the GCO call 360-403-3471

